



## **AX-HOME How to Register Keyfob**

Title:	How To Register Keyfob	Version:	V1.1.0	Date:	17/07/2025
Product:	AX HOME			Page:	1 of 2

## How to Register Keyfob

---

### 1. Add a new keyfob

#### 1) Scan the QR Code.

##### a. Press Any Button to Add

For a keyfob already placed battery in, scan the QR code of keyfob and press any button to add keyfob, the LED indicator will flash green 7 times during the period.



##### b. Power-Up to Add

If battery is not placed in the keyfob, scan the QR code of keyfob and put the battery into it within 30s to add keyfob, LED indicator will flash green for 7 times during the period.



If battery is already placed in the keyfob, press and hold arming button and II button at the same time to add keyfob, during this period LED indicator will flash red first and then flash green for 7 times, release the button when the green light flashes.



2) Enrollment Mode.

Two methods of adding a keyfob in enrollment mode.

a. Enter the enrollment mode to add keyfob (battery unplaced inside), put the battery in, the green light will flash 7 times.

b. Enter the enrollment mode to add keyfob (battery unplaced inside), put the battery in, press and hold arming button and II button at the same time, during this period LED indicator will flash red first, wait until it's flashing orange and release the button, then the indicator will flash green for 7 times.

## 2. Add a keyfob that has been added before

For a keyfob that has been added before, when this keyfob is deleted or needs to be added to a new Control Panel, you can follow the following instructions.

1) Scan the QR Code

Two methods of re-adding a keyfob by scanning the QR code.

a. Open the back cover, scan the QR code of keyfob, remove and re-place the battery in the keyfob within 30s, the LED indicator will flash green 7 times.

b. Or scan the QR code of keyfob without opening the back cover, press and hold arming button and II button at the same time to re-add keyfob, during this period LED indicator will flash red first and then flash green for 7 times, release the button when the green light flashes.

2) Enrollment Mode.

Two methods of re-adding a keyfob in enrollment mode.

a. Enter the enrollment mode to re-add keyfob, remove and re-place the battery in, LED indicator will flash green 7 times.

b. Enter the enrollment mode to re-add keyfob, press and hold arming button and II button at the same time, during this period LED indicator will flash red first, wait until it's flashing orange and release the button, then the indicator will flash green for 7 times.



See Far, Go Further